



ARROWHEAD
R O C K D R I L L



R65
Hydraulic Hammer
Parts Manual




ARROWHEAD
ROCK DRILL

R65 PARTS LIST

Diagram Number	Part Number	Description	Quantity
1	1051301	Moil Point	1
2	1052102	Chuck Housing	1
3	1051311	Tool Retainer	1
4	1011104	Grease Nipple	1
5	1052106	Lower Cylinder Liner	1
6	1052101	Main Body	1
7	1051104	Piston	1
8	1051105	Upper Cylinder Liner	1
9	1051107	Disc Spring Washer	2
10	1051108	Spacer	1
11	1052103	Cylinder Head	1
12	1051201	Valve Housing	1
13	1051202	Valve Bottom Plate	1
14	1051203	Valve Top Plate	1
15	1051204	Valve Spool	1
16	1051205	Plunger	1
17	1011202	Valve Plate Bolts	8
18	1011201	Pressure Plug	1
19	1011113	Gas Valve Adaptor	1
20	1011105	Gas Valve Assembly	1
21	1051401	Seal Kit	1
22	1011304	Hose Adaptors	2
23	1011216	Cylinder Head Bolt Assembly	8
24	1011204	Valve to Body Bolts	10
25	1011102	Inspection Port Plug	1
26	1011215	Dowel Pins	2
27	1011202	Chuck Retaining Bolt Assembly	1
28	1051302	Chisel	1
29	1051303	Blunt	1
30	1051304	1 Piece Post Driver	1
31	1051305	2 Piece Post Driver	1
32	1051306	Tarmac Cutter	1
33	1051307	Power Fist	1
34	1011302	Tool Retaining Rubber Doughnut	1
35	1052309	Hammer Box	1
36	1052313	Decal Set	1
37	1052310	Lower Buffer	1
38	1052314	Upper Buffer	1
39	1052312	Top Bracket	1
40	1011363	Top Bracket Bolts	6
41	1011321	Pressure Hose	2
42	1011112	Gas Valve Spring	1
43	1011111	Gas Valve Shuttle	1
44	1011110	Gas Valve Small O Ring	1
45	1011109	Gas Valve Large O Ring	2
46	1011108	Gas Valve Dowty Washer	1
47	1011107	Gas Valve Body	1
48	1011106	Gas Valve Dust Cap	1



ARROWHEAD
ROCK DRILL



ARROWHEAD R65 POWERCELL BREAKDOWN



ARROWHEAD
ROCK DRILL



40



39



38



41

41



37



35

34



36
(Decal)

ARROWHEAD R65 HAMMER BREAKDOWN



ARROWHEAD
ROCK DRILL



GAS VALVE ASSEMBLY PARTS BREAKDOWN